

IMPORTANT INFORMATION!

(In the event of unplugging and moving a mobile heater or unplugging a wall mounted radiator please follow the steps below)

Thermostat/Receiver Re-set

ON THERMOSTAT

- Turn dial to the off position (Fully anti-clockwise)

ON THE HEATER

- Turn the heater off at the wall for 10 secs
- Turn heater on at wall

ON THE HEATER PRESS

- Press and keep holding the large button on the receiver for 30 seconds, within the 30 seconds keep pressing the button, after Approximately 10 seconds the light will flash and then stop flashing, keep constant pressure on the button and after a further 20 seconds the light will flash rapidly then stop.
- Take your finger off the button.

This next step is very important.

- Press the button again until there is a slow blinking light, when this occurs release the button and the light should be continue flashing.

ON THE THERMOSTAT

- Press and hold down the button on the far right until you see H200 displayed on the screen press the okay button you will first CF01 with 00 flashing at the bottom, press ok and let go.
- Press the ok button repeatedly until you get to CF06
(Please note that you should see 0's at every preceding page until you get to CF06 you will see CF06 CNF Displayed on the screen.)
- Press the + button. The light on the receiver should now be off
- Turn the dial to the SUN position and increase the temperature until you see the flame symbol on the display

(the heater should now be on and the light on the receiver should now be **on and glowing steadily**)

- Using the minus button you can now bring the temperature down to your desired setting